

A240-932 NOTES:

1. APPLY LOCITITE TO ALL THREADED FASTENERS UNLESS OTHERWISE NOTED.
2. FOR LOCATIONS AND QUANTITIES OF LABELING, REFER TO IDI DRAWING #A240-1402.
3. ALIGN HOLE DRILLED INTO SIDE OF HANDLE (ITEM (20) ) WITH SET SCREW INSTALLED INTO THE LEFT HANDLE CAP (ITEM (22) ) BEFORE FULLY TIGHTENING.

